

**2007-2008 DODGE 3500 CAB & CHASSIS AXLE BREATHER RELOCATION**

This kit is for vehicles that have round axle tubes with the breather located approximately 7" from the leaf spring pack. This kit is designed to eliminate interference of the axle breather and the Pacbrake air spring support bracket on Dodge 3500 Cab & Chassis vehicles. The supplied breather fitting is manufactured to a longer length than the stock fitting in order to facilitate vehicles that also use this fitting to hold down the rear brake line junction block.

Install the axle breather kit BEFORE proceeding to install the Pacbrake HP10002 Air Suspension Kit.

- STEP 1**            On the drivers side of the rear axle, locate the axle breather. Remove the rubber hose from the barbed breather fitting and remove the fitting.
- STEP 2**            Measure the grip length of the factory fitting. Cut the supplied fitting to the same measurement. Debur threads and blow out breather passage to ensure no debris can enter the differential. Install the supplied jam nut and then the o-ring onto the fitting.
- STEP 3**            Install this assembly into the axle and adjust to maximum height of 1". This will allow it to fit under the air spring support bracket of the HP10002 kit. Make sure to have the open port of the breather pointing towards the rear of the vehicle.
- STEP 4**            Apply thread sealant to the 1/8" NPT threads of the barbed fitting. Install the 1/8" NPT x 3/8" barbed fitting into the breather fitting. Push on the factory breather hose and proceed to install the HP10002 Air Suspension Kit.