



AIR SUSPENSION APPLICATION CHART

[DODGE](#) | [FORD](#) | [GMC/CHEVROLET](#) | [MAZDA](#) | [STERLING](#) | [TOYOTA](#) | [UNIVERSAL FIT](#)

DODGE

YEAR	MODEL	DRIVE TRAIN	DRILL? Y/N	INSIDE/OUTSIDE FRAME MOUNT	KIT NUMBER
1969-1993	D-150, W-100, W-150 (HEAVY LOADS)	2WD/4WD	Y	OUTSIDE	HP10019
1969-1993	D-150, W-100, W-150	2WD/4WD	Y	OUTSIDE	HP10033*
1969-1993	D-250, W-250	2WD/4WD	Y	OUTSIDE	HP10019
1969-1993	D-350, W-350	2WD/4WD	Y	OUTSIDE	HP10019
1974-1993	RAM CHARGER	2WD/4WD	Y	OUTSIDE	HP10033*
1987-2004	DAKOTA	4WD	Y	OUTSIDE	HP10033*
1994-2001	RAM 1500	2WD/4WD	Y	OUTSIDE	HP10033*
1994-2001	RAM 1500 (HEAVY LOADS)	2WD	Y	OUTSIDE	HP10019
1994-2002	RAM 2500, RAM 3500	2WD/4WD	Y	OUTSIDE	HP10019
2000-2001	DAKOTA RT	2WD	Y	OUTSIDE	HP10033*
2002-2008	RAM 1500 (HEAVY LOADS)	2WD/4WD	N	INSIDE	HP10071
2003-2012	RAM 2500, RAM 3500	4WD	N	INSIDE	HP10002
2003-2012	RAM 2500, RAM 3500	2WD	N	INSIDE	HP10089
2007-2011	RAM 4500, RAM 5500 (CHASSIS CAB)	2WD/4WD	N	INSIDE	HP10121
2007-2009	SPRINTER, 2500	2WD	Y	INSIDE	HP10147
2007-2012	RAM 3500 (CHASSIS CAB)	2WD/4WD	N	INSIDE	HP10002
<i>The HP10136 must also be purchased for vehicles that have a round axle tube with the breather located approximately 7" from the spring pack. This kit is designed to eliminate interference of the axle breather and the Pacbrake Air Spring support bracket of the axle breather and the Pacbrake Air Spring support bracket on the Dodge 3500 Cab and Chassis vehicles.</i>					+ HP10136

***THE HP10033 KIT REQUIRES 6" BETWEEN THE TIRE AND FRAME**

**NOTE - HP10019 KITS FIT WITH A REESE 5th WHEEL RAIL KIT (MODELS 30033, 30035 & 30729); HP10070 KITS FIT WITH A DRAW TITE 15000 5th WHEEL HITCH; THE HP10002 KITS FIT WITH THE 3349 & 3319 SUPERGLIDE 5th WHEEL RAIL KITS ON 4WD VEHICLES
THE HP10089 KITS WILL NOT FIT WITH THE 3349 & 3319 SUPERGLIDE 5th WHEEL RAIL KITS ON 2WD VEHICLES**

FORD

YEAR	MODEL	DRIVE TRAIN	DRILL? Y/N	INSIDE/OUTSIDE FRAME MOUNT	KIT NUMBER
1966-1996	F-100, F-150 (HEAVY LOADS)	4WD	Y	OUTSIDE	HP10019
1966-1996	F-100, F-150 (LIGHT LOADS)	4WD	Y	OUTSIDE	HP10033*
1968-1996	F-100, F-150 (HEAVY LOADS)	2WD	Y	OUTSIDE	HP10019
1968-1996	F-100, F-150 (LIGHT LOADS)	2WD	Y	OUTSIDE	HP10033*
1969-1979	F-250 (UNDER 7500 GVWR)	2WD	Y	OUTSIDE	HP10019
1970-1997	F-350	2WD	Y	OUTSIDE	HP10019
1980-1996	BRONCO	4WD	Y	OUTSIDE	HP10033*
1980-1996	F-250	2WD	Y	OUTSIDE	HP10019
1980-1997	F-250 ('97 HEAVY DUTY OVER 8600 GVWR)	4WD	Y	OUTSIDE	HP10019
1980-1997	F-350 (EXCEPT SUPER HD CHASSIS)	4WD	Y	OUTSIDE	HP10019
1983-1990	BRONCO II	4WD	Y	OUTSIDE	HP10033*
1997-1998	F-250 LIGHT DUTY (UNDER 7500 GVWR)	2WD/4WD	Y	OUTSIDE	HP10019
1997-2004	F-150 (INCLUDING HERITAGE)	2WD/4WD	Y	OUTSIDE	HP10033*
1999-2004	F-350 SUPER DUTY (11,200 GVWR & UNDER)	2WD	Y	OUTSIDE	HP10019
1998-2010	RANGER**	2WD/4WD	Y	OUTSIDE	HP10019
1999-2010	F-250, F-350 SUPER DUTY	2WD/4WD	Y	OUTSIDE	HP10070
2010-2012	F-250, F-350 SUPER DUTY (WILL NOT FIT VEHICLES WITH FACTORY INSTALLED 5TH WHEEL HITCH)	2WD/4WD	Y	OUTSIDE	HP10070
2004-2008	F-150 (HEAVY LOADS) (WILL NOT FIT FX2)	2WD/4WD	N	OUTSIDE	HP10004

***THE HP10033 KIT REQUIRES 6" BETWEEN THE TIRE AND FRAME**

****WILL ONLY FIT WITH STOCK WHEELS AND TIRES**

NOTE - HP10019 KITS FIT WITH A REESE 5th WHEEL RAIL KIT (MODELS 30033, 30035 & 30729); HP10070 KITS FIT WITH A DRAW TITE 15000 5th WHEEL HITCH;



AIR SUSPENSION APPLICATION CHART

[DODGE](#) | [FORD](#) | [GMC/CHEVROLET](#) | [MAZDA](#) | [STERLING](#) | [TOYOTA](#) | [UNIVERSAL FIT](#)

GMC / CHEVROLET

YEAR	MODEL	DRIVE TRAIN	DRILL? Y/N	INSIDE/OUTSIDE FRAME MOUNT	KIT NUMBER
1968-1987	C-3500	2WD	Y	OUTSIDE	HP10019
1969-1991	JIMMY/BLAZER	4WD	Y	OUTSIDE	HP10033*
1973-1991	JIMMY/BLAZER	2WD	Y	OUTSIDE	HP10033*
1973-1987	C-1500, C-2500, C-10, C-20, C-30	2WD	Y	OUTSIDE	HP10019
1973-1987	K-10 & K-1500	4WD	Y	OUTSIDE	HP10033*
1988-1998	C-1500, K-1500	2WD/4WD	Y	OUTSIDE	HP10033*
1988-1998	SIERRA/SILVERADO 1500*	2WD/4WD	Y	INSIDE	} HP10088/ HP10120
1988-1998	SIERRA/SILVERADO 2500*	2WD/4WD	Y	INSIDE	
1999-2000	SIERRA/SILVERADO 2500 (DRUM BRAKES ONLY)*	2WD/4WD	Y	INSIDE	
1988-2000	SIERRA/SILVERADO 3500*	2WD/4WD	Y	INSIDE	
<i>*If the frame to axle pad distance is 7.25" or less, use kit HP10120</i>					
1999-2004	SIERRA/SILVERADO 2500	2WD/4WD	N	INSIDE	HP10072
1999-2007	SIERRA/SILVERADO 1500	2WD/4WD	Y	OUTSIDE	HP10033*
2001-2006	SIERRA/SILVERADO 1500HD (HEAVY LOADS)	2WD/4WD	N	INSIDE	HP10072
2001-2010	SIERRA/SILVERADO 2500HD, 3500 <i>Not for commercial cab and chassis</i>	2WD/4WD	N	INSIDE	HP10005
2001-2005	SILVERADO 1500HD	2WD/4WD	Y	OUTSIDE	HP10033*
2001-2008	SIERRA 1500HD	2WD/4WD	Y	OUTSIDE	HP10033*
2007-2011	SIERRA/SILVERADO 1500	2WD/4WD	N	OUTSIDE	HP10144

***THE HP10033 KIT REQUIRES 6" BETWEEN THE TIRE AND FRAME**

NOTE - HP10019 KITS FIT WITH A REESE 5th WHEEL RAIL KIT (MODELS 30033, 30035 & 30729); HP10070 KITS FIT WITH A DRAW TITE 15000 5th WHEEL HITCH:

MAZDA

YEAR	MODEL	DRIVE TRAIN	DRILL? Y/N	INSIDE/OUTSIDE FRAME MOUNT	KIT NUMBER
1998-2010	MAZDA PICK-UPS**	2WD/4WD	Y	OUTSIDE	HP10019

****WILL ONLY FIT WITH STOCK WHEELS AND TIRES**

STERLING

YEAR	MODEL	DRIVE TRAIN	DRILL? Y/N	INSIDE/OUTSIDE FRAME MOUNT	KIT NUMBER
2007-2011	BULLET 4500, BULLET 5500 (CHASSIS CAB)	2WD/4WD	N	INSIDE	HP10121

TOYOTA

YEAR	MODEL	DRIVE TRAIN	DRILL? Y/N	INSIDE/OUTSIDE FRAME MOUNT	KIT NUMBER
2001-2006	TOYOTA TUNDRA** / ***	2WD/4WD	N	OUTSIDE	HP10126
2001-2006	TOYOTA TUNDRA** / *** <i>Trucks in which the upper jounce bumper pad protrudes 1" below the frame</i>	2WD/4WD	N	OUTSIDE	HP10158
2007-2012	TOYOTA TUNDRA** / ***	2WD/4WD	N	OUTSIDE	HP10128

****WILL ONLY FIT WITH STOCK WHEELS AND TIRES**

*****All Tundra kits require a minimum of 5" between the tire and the frame**

UNIVERSAL FIT

YEAR	MODEL	DRIVE TRAIN	DRILL? Y/N	INSIDE/OUTSIDE FRAME MOUNT	KIT NUMBER
N/A	FABRICATORS AIR SPRING KIT (SMALL AIR SPRING) <i>Suggested for rear suspension</i>	N/A	N/A	N/A	HP10130
N/A	FABRICATORS AIR SPRING KIT (LARGE AIR SPRING) <i>Suggested for front suspension</i>	N/A	N/A	N/A	HP10086